



Sensorsoft® Temperature and Humidity Meter User Manual

Models SS6610J and SS6610C

Manual P/N 071-0080 Rev 5 March 16, 2017

Copyright © 2003-2017 Sensorsoft Corporation, All rights reserved.
Sensorsoft is a registered trademark of Sensorsoft Corporation.

Table of Contents

Overview	4
About this Manual	4
Installing the Sensorsoft Temperature and Humidity Meter	5
Choosing an Installation Location	5
Connecting the Sensorsoft Temperature and Humidity Meter to a serial port	5
SS6610C Sensorsoft Temperature and Humidity Meter Specifications	7
SS6610J Sensorsoft Temperature and Humidity Meter Specifications	8
Resolution, Accuracy and Calibration	9
Avoid making invalid judgements or comparisons	9
Use an appropriate measurement instrument to make comparisons	9
Use the correct method to make comparisons	10
What to do, if you believe the Sensorsoft device is reading incorrectly	10
Making extension cables for C-Suffix Sensorsoft Devices	11
Making communication cables for J-Suffix Sensorsoft Devices	12
Writing programs for the Sensorsoft Temperature and Humidity Meter	15
Sending commands to the Sensorsoft Temperature and Humidity Meter	15
Receiving responses from the Sensorsoft Temperature and Humidity Meter	17
Converting DATA-byte(s) to temperature readings	18
Converting DATA-byte(s) to relative humidity readings	20
Reading the Sensorsoft ID Record	21
Getting Help	23
Limited Warranty	23
Technical Support	23
Product Returns	23

Overview

The SS6610J and SS6610C Sensorsoft Humidity Temperature Meters are RS232 compatible serial devices based on the Sensorsoft Device Protocol. The SS6610J/C with built-in temperature and humidity sensors are intended for applications where the customer needs to monitor a room, warehouse or equipment.

Sensorsoft devices offer the following benefits over other RS232 serial devices:

- Powered from the serial port (no external power or battery required)
- CRC error detection (detects transmission errors and improves reliability)
- Virtually unlimited cable lengths (1000 ft)
- Plug and go operation (little or no user configuration required)

About this Manual

The Sensorsoft Temperature and Humidity Meter may also be referred to as a Sensorsoft device or SSD (Sensor Soft Device) throughout this manual.

Installing the Sensorsoft Temperature and Humidity Meter

Installation of the Sensorsoft Temperature and Humidity Meter is composed of the following steps:

- Choosing an Installation Location
- Connecting the Sensorsoft Temperature and Humidity Meter to a serial port
- Starting the Sensorsoft software. Please refer to the specific software manual that applies to your installation.

Choosing an Installation Location

Locate the Sensorsoft Temperature and Humidity Meter close to the equipment or airflow you are monitoring. Since the SS6610J/C is not waterproof or weatherproof, keep the following rules in mind:

- Keep the Sensorsoft device housing out of contact with direct sunlight, UV exposure and dripping water.
- Protect the Sensorsoft device from high traffic areas that could wear/damage the housing or cable.
- Never allow the plastic housing of the Sensorsoft device to come into contact with harsh chemicals or cleaning agents. If it needs to be cleaned, do so with a damp cloth or vacuum cleaner.

Use a Velcro fastener (P/N F1000 or F1001) to affix the Sensorsoft device to a stable surface.

Connecting the Sensorsoft Temperature and Humidity Meter to a serial port

If you have a SS6610C (C-Suffix) Sensorsoft Temperature and Humidity Meter, plug its molded DB-9F connector into an available RS232 serial port connector (DB-9M) on your computer or device server.

If you have an SS6610J (J-Suffix) Sensorsoft Temperature and Humidity Meter, use the appropriate C20XX cable to connect this device to your computer or device server. Please refer to the Sensorsoft price list for available types.

If you intend to make your own custom cable for a J-Suffix Sensorsoft device, please refer to *Making communication cables for J-Suffix Sensorsoft Devices*.

If you are connecting a Sensorsoft Temperature and Humidity Meter to a device server, please be sure to configure the port as follows:

- 1200 bps, 8 bits, no parity, 1 stop bit
- Turn off autobaud
- Flow control set to none
- Non-telnet binary (raw) transfer mode
- Assert RTS and DTR always

Refer to your device server's documentation for more details on the above.

SS6610C Sensorsoft Temperature and Humidity Meter Specifications

Temperature Measurement Range: -40 °C to +60 °C (-40 °F to +140 °F)

Temperature Resolution or precision: 0.1 °C (0.18 °F) and 0.5 °C (0.9 °F)

Temperature Accuracy: +/- 0.5 °C (+/- 0.9 °F) between 0 °C to +60 °C (32 ° to 140 °F)
+/- 1 °C (1.8 °F) over remainder of temperature range

Relative Humidity Measurement Range: 0 to 100 % RH

Relative Humidity Resolution or precision: 0.1 % RH and 1 % RH

Relative Humidity Accuracy: +/- 3 % RH between 10 % RH and 90 % RH
+/- 5 % RH below 10 % RH and above 90 % RH

Relative Humidity Long Term Stability: < 1 % RH/year

Calibration: Calibrated at the factory. Re-calibration in the field is not possible, but sensors can be replaced.

Maximum measurement rate: One reading every second

Housing Dimensions: 8 cm (3.1") x 4 cm (1.6") x 2 cm (0.8")

Housing Material: Injection molded ABS thermoplastic

Housing Color: Light gray

Sensor type: Semiconductor

Communications cable: Integrated 6 m (20 ft.) cable with DB-9F (female) mini D-SUB connector

Power source: Port-powered (RTS and DTR, both asserted).

Power supply current drain: < 10 mA

Communications Interface: RS232C using TX,RX,RTS,DTR and GND. One device per serial port.

Maximum extension cable length: 305 m (1000 ft.) using recommended cable type. Low capacitance shielded cable or UTP is recommended.

Communications Protocol: Sensorsoft Device Protocol, Version 2.1

Error control: 16 bit CRC (cyclic redundancy checking) for detection of communication errors between the device and host computer.

SS6610J Sensorsoft Temperature and Humidity Meter Specifications

Temperature Measurement Range: -40 °C to +60 °C (-40 °F to +140 °F)

Temperature Resolution or precision: 0.1 °C (0.18 °F) and 0.5 °C (0.9 °F)

Temperature Accuracy: +/- 0.5 °C (+/- 0.9 °F) between 0 °C to +60 °C (32 ° to 140 °F)
+/- 1 °C (1.8 °F) over remainder of temperature range

Relative Humidity Measurement Range: 0 to 100 % RH

Relative Humidity Resolution or precision: 0.1 % RH and 1 % RH

Relative Humidity Accuracy: +/- 3 % RH between 10 % RH and 90 % RH
+/- 5 % RH below 10 % RH and above 90 % RH

Relative Humidity Long Term Stability: < 1 % RH/year

Calibration: Calibrated at the factory. Re-calibration in the field is not possible, but sensors can be replaced.

Maximum measurement rate: One reading every second

Housing Dimensions: 8 cm (3.1") x 4 cm (1.6") x 2 cm (0.8")

Housing Material: Injection molded ABS thermoplastic

Housing Colour: Light gray

Sensor type: Semiconductor

Communications connector: 8 position modular jack, (accepts 8 position plug RJ45)

Power source: Port-powered (RTS and DTR, both asserted) or via External DC power connector

Power supply current drain: < 10 mA

External DC power connector: 2.1 mm power jack, automatic polarity correction and over-voltage protection.

External power supply voltage: 6.0 - 12.0 VDC

Communications Interface: RS232C using TX,RX,RTS,DTR and GND. One device per serial port.

Maximum communications cable length: 305 m (1000 ft.) using recommended cable type. Low capacitance shielded cable or UTP is recommended.

Communications Protocol: Sensorsoft Device Protocol, Version 2.1

Error control: 16 bit CRC (cyclic redundancy checking) for detection of communication errors between the device and host computer.

Resolution, Accuracy and Calibration

The terms resolution, accuracy and calibration frequently cause misunderstanding for many individuals who have not been trained in metrology. We endeavor here to explain these terms and how they might affect your application of Sensorsoft devices.

Resolution or precision is the fineness of the measurement. It is usually specified in terms of the smallest unit that can be resolved.

Accuracy is the trueness of the measurement or how close it can be to the true value (National Standard). Accuracy is often specified as a percentage (i.e. +/- 3 % of reading), or a fixed value (i.e. +/- 0.5) that the reading can vary from the true value.

Calibration is a process where accuracy is verified (and often corrected) with respect to a standard. Calibrations are routinely carried out to certify that a device has not lost its accuracy, linearity and stability. Calibrations can be carried out at a time interval that is required by your industry. In many cases this is done at least once every year. When a calibration or verification takes place, it must always be done with equipment that has significantly better accuracy and resolution than the device under test. When a calibration check is performed on a Unit under Test with an instrument that is proven as traceable to the National Standards Laboratory, the Unit under Test is also considered to be traceable.

Avoid making invalid judgements or comparisons

Using any of the following measurement devices or situations is **unacceptable** for comparing to, or judging the accuracy of a Sensorsoft device:

- Low cost measurement device purchased from a retail store
- Digital display on HVAC or cooling/heating equipment
- Location of the active sensing element is unknown or hidden
- Measurement device has its active sensing element more than one inch (2.5 cm) away from the Sensorsoft device's sensing element
- Measurement device has lower accuracy specifications as compared to the Sensorsoft device
- Measurement device has unknown accuracy specifications
- Measurement device has not been calibrated within one year, has no calibration certificate or is not traceable to a reference standard

Use an appropriate measurement instrument to make comparisons

We recommend one of the following instruments (or equivalent) that has a recently dated traceable calibration certificate, for judging the accuracy or stability of your Sensorsoft device:

- Vaisala HM40 series Hand held Humidity & Temperature Meter (approx. price \$500-1000 US)
- Vaisala HMT330 series Humidity & Temperature Transmitter and external probe (Wall mount, RS232 interface, order with 115/230 VAC power supply, approx. price \$1900-2500 US)

More details about the above instruments are available on Vaisala's web site:

<http://www.vaisala.com>

Use the correct method to make comparisons

Keep the following points in mind when checking the Sensorsoft device for accuracy or stability:

1. Use one of the above recommended instruments (or equivalent) that has a recent calibration certificate (within one year)
2. The sensing elements of Sensorsoft device and the traceable instrument must be touching each other or within one inch (2.5 cm)
3. Allow sufficient time (30-60 minutes) for the Sensorsoft device and the traceable measurement instrument to acclimatize to the environment
4. Make sure you know how to get a live (up to the second) temperature or humidity reading from the Sensorsoft device while using the host software
5. For reading the Sensorsoft device use the higher resolution variables, not the lower resolution variables, during the comparison
6. Do have the published accuracy specifications for the Sensorsoft device and the traceable measurement instrument readily available for comparison

What to do, if you believe the Sensorsoft device is reading incorrectly

If after following the above method you find that the Sensorsoft device is not reading within its stated specifications you can obtain an RMA to return the Sensorsoft device to our factory for repair. See Product Returns at the end of this manual. Charges may apply if the unit is out-of-warranty or if we find no evidence that the device is out-of-calibration.

Making extension cables for C-Suffix Sensorsoft Devices

In some applications it is not possible to use pre-assembled cables. When installing the Sensorsoft device at a remote location, it may be necessary to run cables through walls, ceiling or conduits where connectors would get jammed. In this situation it makes sense to run the cables and then terminate them, on-site, using hand tools. Further, if your host serial port is of the DCE type (some multi-port serial cards) it will be necessary to make your own cables. The following details will assist you in doing that.

A properly made cable will allow your Sensorsoft device to operate reliably over long distances.

PIN-OUT OF THE DB-9F CONNECTOR ON A C-SUFFIX SENSORSOFT DEVICE

Note: Only positions used in Sensorsoft device application are shown

Position	Function
2	TX (data to computer)
3	RX (data from computer)
4	POWER (connects to DTR on computer)
5	Ground
7	POWER (connects to RTS on computer)

The following are suggested specialized tools and parts needed to make good quality extension cables:

Hand Tools:

AMP Crimping Tool P/N 90312-1 or 90302-1, for subminiature D pin or socket contacts

AMP PROCRIMPER P/N 58448-2, for subminiature D pin or socket contacts

AMP Insertion/Extraction Tool P/N 91285-1, for subminiature D connector contacts

Materials:

Berk-Tek UTP (Unshielded Twisted Pair) round stranded cable, P/N 540036--TP

(4 pair, 8-#24 AWG wires, category 4 or better, 75 C)

AMP DB-9 receptacle subminiature D connector (crimp-snap-in), P/N 205203-1 or -3

AMP DB-25 receptacle subminiature D connector (crimp-snap-in), P/N 205207-1 or 207463-1

AMP socket crimp contact for subminiature D connectors, P/N 1-66504-0

AMP pin crimp contact for subminiature D connectors, P/N 1-66506-0

Making communication cables for J-Suffix Sensorsoft Devices

In some applications it is not possible to use pre-assembled cables. When installing the Sensorsoft device at a remote location, it may be necessary to run cables through walls, ceiling or conduits where connectors would get jammed. In this situation it makes sense to run the cables and then terminate them, on-site, using hand tools. Further, if your host serial port is of the DCE type (some multi-port serial cards) it will be necessary to make your own cables. The following details will assist you in doing that.

A properly made cable will allow your Sensorsoft device to operate reliably over long cable lengths up to 305 m (1000 ft) long. You may connect the Sensorsoft device to the port with as little as three wires (RX, TX and GND) using inexpensive unshielded telephone wire. However the host may need to set the number of retries high in order to overcome the effect of occasional noise/interference and would also require the use of an external power supply at the Sensorsoft device.

The Sensorsoft device modular jack connector uses the same UTP wire map as 10-BASE-T and ISDN. It is therefore possible to use this type of cabling system for Sensorsoft devices.

PIN-OUT OF THE MODULAR 8 POSITION JACK/PLUG ON A SENSORSOFT DEVICE

Note: Terminal No. 1 is the terminal to the extreme left as you face the cable opening, latch tab down.

Terminal	Function	UTP wire color (solid-tracer)
1	ST Receive Data	white-green
2	Ground	green
3	ST Transmit Data	white-orange
4	Power +V	blue
5	Ground	white-blue
6	Ground	orange
7	Power +V	white-brown
8	Ground	brown

The following are suggested specialized tools and parts needed to make good quality cables:

Hand Tools:

AMP Crimping Tool P/N 1-231652-0 or 2-231652-1, for modular plugs

AMP 8 position modular die set P/N 853400-1

AMP Crimping Tool P/N 90312-1 or 90302-1, for subminiature D pin or socket contacts

AMP PROCRIMPER P/N 58448-2, for subminiature D pin or socket contacts

AMP Insertion/Extraction Tool P/N 91285-1, for subminiature D connector contacts

Materials:

Berk-Tek UTP (Unshielded Twisted Pair) round stranded cable, P/N 540036--TP

(4 pair, 8-#24 AWG wires, category 4 or better, 75 C)

AMP 8 position modular plug for round stranded wire cables, P/N 5-554169-3 (CAT4)

AMP 8 position modular plug for round stranded wire cables, P/N 5-557961-3 (CAT5)

AMP DB-9 receptacle subminiature D connector (crimp-snap-in), P/N 205203-1 or -3

AMP DB-25 receptacle subminiature D connector (crimp-snap-in), P/N 205207-1 or 207463-1

AMP socket crimp contact for subminiature D connectors, P/N 1-66504-0

AMP pin crimp contact for subminiature D connectors, P/N 1-66506-0

Cable P/N C2000
9 pin Serial Port to Sensorsoft Device
DB-9F to RJ45 modular plug

9 pin Port			Sensorsoft Device		
3	TX	white-green	RX	1	
2	RX	white-orange	TX	3	
4	DTR	white-brown	POWER +V	7	
7	RTS	blue	POWER +V	4	
5	SIGNAL GND	green	GND	2	

P/N C2000 is for use with PC's and most other devices which have a 9 position serial port. F indicates female/socket type connector.

Cable P/N C2001 and C2002
DTE Serial Port to Sensorsoft Device
DB-25 to RJ45 modular plug

DTE Port			Sensorsoft Device		
2	TX	white-green	RX	1	
3	RX	white-orange	TX	3	
20	DTR	white-brown	POWER +V	7	
4	RTS	blue	POWER +V	4	
7	SIGNAL GND	green	GND	2	

P/N C2002 is for use with Sun SPARCstation or SPARCserver serial ports A or B. The DTE end of this cable uses a DB-25M connector. P/N C2001 is for use with PC's which have a DB-25 connector. The DTE end of this cable uses a DB-25F connector. M indicates male/pin type connector. F indicates female/socket type connector.

Cable P/N C2012
DCE Serial Port to Sensorsoft Device
DB-25M to RJ45 modular plug

DCE Port			Sensorsoft Device		
3	TX	white-green	RX	1	
2	RX	white-orange	TX	3	
6	DSR	white-brown	POWER +V	7	
5	CTS	blue	POWER +V	4	
7	SIGNAL GND	green	GND	2	

P/N C2012 is for use with some multiport cards and terminal servers which have a DCE pin-out. M indicates male/pin type connector.

Writing programs for the Sensorsoft Temperature and Humidity Meter

The following describes how to write your own programs for the Sensorsoft Temperature and Humidity Meter. This Sensorsoft device uses a binary, packet-formatted, master-slave protocol. All data is represented in the **little endian format** - least significant byte is first and the most significant byte is last. Your host computer (master) must send commands to and receive responses back from the Sensorsoft device (slave).

Use the following parameters when programming the serial port where the Sensorsoft device is connected:

Bit rate: 1200 bps
Bits: 8
Parity: none
Stop bits: 1
Flow control: none
Null discard: do not strip NULL bytes

In order to make use of the port powered feature of the Sensorsoft device you must enable serial port lines DTR and RTS when the port is opened. A delay of 1-2 seconds is required after opening the serial port before any commands are sent to the Sensorsoft device. This delay allows the Sensorsoft device to power-up correctly before it receives any commands and prevents incorrect readings.

You should also be aware that the Sensorsoft device has an inter-packet retry time-out delay. This delay is one (1) second and is encoded into the Sensorsoft device's firmware. If your program sends a command to the Sensorsoft device and it receives no response, your program must wait at least one (1) second before re-sending that command. Possible reasons that a Sensorsoft device may ignore your commands can be due to data transmission (CRC) errors or improper power-up delay during hot plugging.

Sending commands to the Sensorsoft Temperature and Humidity Meter

Each command packet your host sends to the Sensorsoft Temperature and Humidity Meter must be in the following format:

<CMD-byte> <PACKETlength-bytes> <ADDRESS-bytes> <ARGUMENT-byte> <CRC-bytes>

CMD-byte

A single byte command indicating the desired action the Sensorsoft Temperature and Humidity Meter device should carry out.

PACKETlength-bytes

Two bytes indicating the total length of the packet from start to finish (including CRC bytes).

ADDRESS-bytes

The six-byte (48-bit) address of the device you are sending the command to. For RS232 Sensorsoft devices this is always decimal 1.

ARGUMENT-byte

The number of the Sensorsoft Temperature and Humidity Meter's internal register you want to read or write. This byte is required for the humidity or temperature command. This byte is not required for the status command. Register numbers are bolded in the examples below.

CRC-bytes

A two byte (16 bit) Cyclic Redundancy Check that is calculated on the entire packet from the CMD byte to the last ARGUMENT byte or ADDRESS byte. In the examples below, the last two bytes in each command string are CRC bytes that were pre-calculated.

Send the following bytes to request a status reading:

<C1h><0Bh><00h><01h><00h><00h><00h><00h><00h><47h><98h>

Send the following bytes to request a relative humidity reading in % RH (1 % resolution):

<C5h><0Ch><00h><01h><00h><00h><00h><00h><00h><01h><0Eh><49h>

Send the following bytes to request a relative humidity reading in % RH (0.1 % resolution):

<C5h><0Ch><00h><01h><00h><00h><00h><00h><02h><6Dh><79h>

Send the following bytes to request a temperature reading in Celsius (0.5 C resolution):

<C5h><0Ch><00h><01h><00h><00h><00h><00h><03h><4Ch><69h>

Send the following bytes to request a temperature reading in Celsius (0.1 C resolution):

<C5h><0Ch><00h><01h><00h><00h><00h><00h><04h><ABh><19h>

Receiving responses from the Sensorsoft Temperature and Humidity Meter

Each response packet the Sensorsoft device returns is in the following format:

<RESPONSE-byte> <PACKETlength-bytes> <DATA-byte(s)> <CRC-bytes>

RESPONSE-byte

A single byte response code indicating the type of response. Valid codes are 90 hex or 94 hex.

PACKETlength-bytes

Two bytes indicating the total length of the packet from start to finish (includes CRC bytes).

DATA-byte(s)

Most responses return additional data in the form of byte(s). In response to a temperature query command, two or four bytes are returned for DATA-byte(s). In response to a status command, one byte is returned for DATA-byte(s). See *SENSORSOFT DEVICE STATUS BYTE FORMAT* chart.

CRC-bytes

A two byte (16 bit) Cyclic Redundancy Check. This placeholder is filled with CRC bytes calculated by the Sensorsoft device on the entire packet from the RESPONSE byte to the last DATA-byte. These bytes allow the host to verify the integrity of the response packet. You may choose to use or ignore these bytes depending on your programming skill or application.

The Sensorsoft device returns a normal RESPONSE-byte (**90 hex**) in acknowledgement that the previous host command was received and executed without errors. The Sensorsoft device only acknowledges correctly received commands that have no CRC errors. If the Sensorsoft device detects a CRC error in a received command packet, it does not respond to the command. It is considered the job of the host to time-out and re-transmit that command packet.

When an internal problem occurs inside the Sensorsoft device it sends out an abnormal response byte (**94 hex**) in response to any command from the host. If the host receives this response byte, it must immediately read and interpret the Sensorsoft device's status to determine the problem. See *SENSORSOFT DEVICE STATUS BYTE FORMAT* chart.

The generator polynomial used for the CRC is hexadecimal 1021. The following references provide information for readers who wish to use the CRC capability;

- Calculating CRC's by Bits and Bytes, Greg Morse, Byte Magazine, September 1986, Pg. 115-124
- Implementing CRC's, Jack Crenshaw, Embedded Systems Programming Magazine, January 1992, Pg. 18-45
- Technical Aspects of Data Communication, John McNamara, Digital Equipment Press 1982, Pg. 110-122
- Data and Computer Communications, 2nd edition, William Stallings, Macmillan Publishing, Pg. 107-112
- The modem reference: the complete guide to selection, installation, and applications, 2nd edition, Michael A Banks, Brady Publishing 1991, Pg. 27-42

SENSORSOFT DEVICE STATUS BYTE FORMAT

BIT	NAME	DESCRIPTION
0	Low power supply	Voltage is unacceptable for reliable operation
1	IRQ enable	N/A
2	IRQ pending	N/A
3	Power-up	Sensorsoft device just powered-up
4	Tamper	Sensor element is disconnected or broken
5	NV option	N/A
6	EEPROM fail	N/A
7	Future use	N/A

A logic one condition on any of these bits indicates the condition is set or active. Otherwise they are reset to logic zero. It is a good practice for the host to check the status of the Sensorsoft device on a regular basis in case a bit changes state.

If bit 0 is set, this indicates that the Sensorsoft device power supply voltage is too low.

When bit 3 is set, this indicates that the Sensorsoft device has just powered-up. This bit gets reset after the status is read.

When bit 4 is set, this indicates that the sensor element has become damaged or disconnected.

Bits 1,2,5,6 and 7 can be ignored because they are not used in model SS6610.

Converting DATA-byte(s) to temperature readings

The Sensorsoft Temperature and Humidity Meter outputs temperature in two different formats.

The first format is common to all Sensorsoft temperature measuring devices (i.e. ST6105, ST6154) and is easiest for programmers to support. It provides a resolution of 0.5 degree Celsius. Commands that query register 3 in the Sensorsoft Temperature and Humidity Meter will receive a two byte response in the DATA-byte(s) placeholder. It is the job of the host software to convert the DATA-byte(s) to a floating-point number. It is then possible to display readings in Celsius scale. The following procedure explains the steps required:

1. Check the value of the most significant DATA-byte. If it is FFh, the number is negative and requires processing by steps 2,3,4 and 5. If it is 00h, the number is positive and requires processing by steps 3 and 5.
2. Invert the bits of the least significant DATA-byte, then add 1 to it.
3. Convert the least significant DATA-byte to a floating-point number.
4. Multiply the previous by -1 to get the negative result.

5. To obtain a temperature in Celsius, divide the previous result by 2. For Fahrenheit, multiply the Celsius value by 9, divide by 5 and add 32.

SENSORSOFT TEMPERATURE DATA-byte(s) FORMAT

Temperature	Binary		Hex
	MSB	LSB	
+ 125 °C	00000000	11111010	00FAh
+ 85 °C	00000000	10101010	00AAh
+ 70 °C	00000000	10001100	008Ch
+ 25 °C	00000000	00110010	0032h
+ 0.5 °C	00000000	00000001	0001h
0 °C	00000000	00000000	0000h
- 0.5 °C	11111111	11111111	FFFFh
- 25 °C	11111111	11001110	FFCEh
- 40 °C	11111111	10110000	FFB0h
- 55 °C	11111111	10010010	FF92h

Please note that the least significant temperature DATA-byte is in terms of a 0.5 ° C. The sign bit is duplicated into all of the bits of the most significant DATA-byte.

The second format provided by this device for temperature is in IEEE Floating-Point Standard (single precision) and has a useable resolution of 0.1 degree Celsius. Commands that query register 4 in the Sensorsoft Temperature and Humidity Meter will receive a four byte response in the DATA-byte(s) placeholder. Decoding these IEEE Floating-Point bytes is beyond the scope of this document.

Converting DATA-byte(s) to relative humidity readings

The Sensorsoft Temperature and Humidity Meter outputs relative humidity in two different formats.

The first format is common to the Sensorsoft Humidity Meter (i.e. SM6204) measuring device and is the easiest for programmers to support. It provides a resolution of 1 % RH. Commands that query register 1 in the Sensorsoft Temperature and Humidity Meter will receive a one byte response in the DATA-byte(s) placeholder. It is the job of the host software to convert the DATA-byte(s) to an integer number. It is then possible to display relative humidity readings in % RH.

SENSORSOFT HUMIDITY METER DATA-byte(s) FORMAT

% RH	Binary	Hex
0	00000000	00h
10	00001010	0Ah
25	00011001	19h
50	00110011	32h
75	01001011	4Bh
90	01011010	5Ah
100	01100100	64h

The second format provided by this device for relative humidity is in IEEE Floating-Point Standard (single precision) and has a useable resolution of 0.1 % RH. Commands that query register 2 in the Sensorsoft Temperature and Humidity Meter will receive a four byte response in the DATA-byte(s) placeholder. Decoding these IEEE Floating-Point bytes is beyond the scope of this document.

Reading the Sensorsoft ID Record

Every Sensorsoft device (SSD) accepts an identification (ID) command, whose response can be used to uniquely identify the type of SSD currently connected. Specifically, the model number and description can be extracted from the SSD's ID response, allowing application software to determine the specific model of the SSD connected and to configure itself appropriately.

The format of the ID command is identical to the format of all other commands, described earlier.

Send the following bytes to the SSD to request the ID:

Hex <C3h> <0Bh> <00h> <01h> <00h> <00h> <00h> <00h> <00h> <20h> <5Eh>

The ID response contains four variable-length, null-terminated strings. The sequence of four strings begins at the 10th byte in the response packet.

To read the SSD's description, count to the 10th byte in the ID response and extract the following ASCII null-terminated string.

Following this is the manufacturer's name; also a null-terminated string.

The third null-terminated string is the SSD's model number. The model number can be used to uniquely identify the type of SSD, so that your software can configure itself appropriately for different models of SSDs.

The fourth and final null-terminated string is the SSD's firmware version.

Structure of the ID response packet

Byte	Description of field
1	Response byte
2-3	Packet length
4-9	Not used
10	Device name or description (null-terminated)
~	Manufacturer (null-terminated)
~	Model Number (null-terminated)
~	Firmware Version (null-terminated)
~	Record Terminator (FFh)
~	CRC bytes (2)

Sample ID response packet from a SS6610J Sensorsoft Temperature and Humidity Meter

Byte	Contents
1	<90h>
2	<53h>
3	<00h>
4-9	<01h> <00h> <00h> <05h> <03h> <07h>
10	Sensorsoft (R) Humidity Temperature Meter <00h>
~	Sensorsoft Corp. <00h>
~	SS6610 <00h>
~	1.00 <00h>
~	<FFh>
~	<8Eh><B4h>

Getting Help

Limited Warranty

Sensorsoft Corporation warrants this Sensorsoft product to be free from manufacturing defects for a period of two years. This includes parts and labor. All shipping and brokerage fees are your responsibility when returning a Sensorsoft product for warranty claims. The following will void the warranty and 30 day money back guarantee:

- signs of water or chemical damage
- cracks to the housing
- signs of tampering or reverse engineering

Technical Support

If in the unlikely event you should have problems installing or using your Sensorsoft product and the previous sections of this manual have failed to provide a solution, we offer technical support to help you overcome your difficulties (see web site address below). No-charge installation and configuration support is provided for 90 days, after that there is a per-incident fee. Sensorsoft Corporation **does not** provide free support to those wishing to write their own software; this is available on a charge-per-incident basis only. Please contact support for current rates.

World Wide Web: <http://www.sensorsoft.com>

Product Returns

If returning a product or item, please keep in mind the follow guidelines:

- Contact Sensorsoft for an RMA number (Return Material Authorization).
- Provide a detailed explanation or reason for returning the product.
- Return shipments that bear no RMA number (on the outside of the package) or are not prepaid for shipping/clearing charges, will be refused.